

**MANUAL DE INSTALAÇÃO E  
CONFIGURAÇÃO DO LEITOR DE  
CODIGO DE BARRAS  
VERSÃO 0.1**



Setup Commands	
<b>2 Set All Defaults</b> Set all the parameters to the factory default setting.	
<b>1 Start Configuration.</b>	
<b>3 End Configuration</b>	
<b>Abort Configuration</b> Terminate current programming status.	
<b>Version Information</b> Display the decoder version information and date code	



